


Carrier ComfortChoice “Edge”

Customer Education Sheet

The Edge thermostat has two user display modes. When the door is closed, the thermostat displays the current temperature, mode, time, and event notifications (if applicable). No changes can be made with the door closed. When the door is opened, the display automatically changes to allow the user to adjust settings.


Door Closed (Inactive mode)



Current Room Temperature
 Event notification
 Current Time of Day or during event time left

Door Open (Active mode)

Not all icons will be displayed at all times.



- Mode** – Cycles between Off, Cool, Heat, Em heat (HP only)
- Fan** – Auto or ON
- Schedule** – Follow program schedule, hold or vacation
- Done** – Accepts changes and returns to prior screen
- Set** – Used to enter menu for setup options
- Up** – Press this button to raise your set temperature
- Down** – Press this button to lower your set temperature
- “Soft Keys” (6)** – Used to select option shown above

Press the UP/DOWN buttons to temporarily change your temperature


Temporarily Adjusting Setpoints (Owner’s Manual pages 10-11)

1. Open the thermostat door. You will see this image in the lower right corner of the screen. If the thermostat is in Heat or Cool mode, you will only see the applicable setting.
2. Use the UP/DOWN buttons to adjust the setpoint.
3. Your setpoint will be held for 2 hours, or until the next program period is reached.



To Use the Thermostat Manually (Owner’s Manual page 12)

1. Open the thermostat door.
2. Press the SCHEDULE button until the arrow points to “hold” on the screen. Use the UP/DOWN buttons to adjust the setpoint.
3. Your setpoints will be held until you use the SCHEDULE button to take the thermostat off “hold”.




If You Go on Vacation (Owner’s Manual pages 19-20)

You may either place the thermostat on “hold” by following the directions for “To Use the Thermostat Manually”, or the thermostat has a feature that will allow you to place your system on “hold” until a specific date. Please see pages 19-20 in your Owner’s Manual for information on setting this feature.

To Have the Thermostat Follow the Existing Program

1. Open the thermostat door.
2. Press the SCHEDULE button until the arrow points to “follow schedule” on the screen.



To Set a New 7 Day Program (Owner’s Manual pages 14-18)

1. Open the thermostat door.
2. Press the SET button twice.
3. Use the UP/DOWN buttons to select the start hour.
4. Press the soft key below the minutes, then use the UP/DOWN buttons to select the start minute.
5. Press the soft key below the Heat or Cool setpoint, and use the UP/DOWN buttons to select the temperature.
6. Press the soft key below the time period (day) to switch to the evening period. Repeat steps 3-5 to set each of the remaining periods (eve, sleep and wake).
7. Press the DONE button to save your settings.
8. For more advanced programs, including individual days, and weekday/weekend, please see pages 16-18 in your Owner’s Manual.



Use this chart to fill in your desired program settings. The installer will create the program for you.

Current Program Settings											
Wake			Day			Evening			Sleep		
Time	Heat	Cool	Time	Heat	Cool	Time	Heat	Cool	Time	Heat	Cool
Future Program Settings											